


PK16569AL



PUTEKASSE 650L ALUMINIUM













NO

Monteringsanvisning

DELER

Pass på at alle deler og skruer er inkludert og at de er det uskadet før montering av produktet. Hvis enheten er skadet i transport, må enheten ikke monteres før du kontakter forhandleren.

Skadede deler eller skader på maling forårsaket av transport, skal meldes til forhandleren før enheten monteres og tas i bruk. Vær oppmerksom på at noen deler kan være skjult i emballasjen som beskytter delene under transport. Hvis deler mangler, sjekk emballasjen nøye.

Ax1		Bx1		Cx2	
Dx1		Ex1		Fx2	
Gx1		Hx1		Ix20	 M4*8
Jx4	 M4*12	Kx26	 M4	Lx6	
Mx2		Nx2		Ox2	
Px2		Qx1	 7mm	Rx1	 12#
Sx1	 5*50	Tx6	 M4	Ux22	 M4

DELOVERSIKT

No.	Beskrivelse	Antall
A	Lokk	1
B	Bunnpanel	1
C	Vegg, høyre og venstre side	2
D	Bakvegg	1
E	Front	1
F	Lokkspjeld	2
G	Lås	1
H	Låsedel	1
I	M4x8 skrue	20
J	M4x12 skrue	4
K	M4 mutter	26
L	Bein	6
M	Hylse	2
N	Støtdemper for lokk	2
O	Lokkhengsel	2
P	Nøkkel	2
Q	Sekskantnøkkel	1
R	Skiftnøkkel	1
S	Philips skrujern	1
T	M4 mutter	6
U	M4 skive	22

Sett inn alle skruene først, ikke stram til. Stram alle skruer når modulen er ferdig montert.

ADVARSEL!

IKKE BRUK ELEKTRISK VERKTØY FOR Å MONTERE MODULEN.

VERKTØY MED MASKINKRAFT KAN SKADE OVERFLATEBELEGGET PÅ SKRUER OG MALTE DELER PÅ PUTEKASSEN, OG FERDIGMONTERTE SKRUER KAN LØSNE.

TIPS!

Hvis modulen oppleves skjev eller bøyd etter ferdig montering, løsne alle skruene. Rett ut hver del og stram skruene igjen. Putekassen bør monteres på et plant underlag for best mulig resultat.


MONTERING

LEGG ET STYKKE PAPP PÅ GULVET (F.EKS ESKEN PRODUKTET ER PAKKET I) FOR Å UNNGÅ RIPER PÅ DELENE UNDER MONTERING.

1

Monter alle skruer og muttere.
Ikke stram før trinn 4.
Monter del C1, C2 og D sammen
med 8 stk I-skruer, 8 stk
U-skiver og 8 stk K-muttere.


Ix8
Kx8
Ux8



2

Monter del B med 3 stk L-fot, 3 stk
U-skiver, 3 stk T-muttere og 3 stk
K-muttere.


Kx3
Lx3
Tx3
Ux3



MONTERING

3


Monter del E med 2 stk I-skruer, 2 stk U-muttere og 2 stk K-muttere.



Ix2
Kx2
Ux2

4

Monter del B med 3 stk L-fot, 3 stk U-skiver, 3 stk T-muttere og 3 stk K-muttere. Fest del E med 6 stk I-skruer, 6 stk U-muttere og 6 stk K-muttere.




Ix6
Kx9
Lx3
Tx3
Ux9

Stram **alle** skruer etter steg 4.


MONTERING

5 Monter låsedel G og hylsedel M.



Gx1
Mx2


6 Plasser låsedel H og fest med 1 skrue.



Hx1


MONTERING

- 7** Monter 2 stk O-hengslet med 4 stk J skruer.
Plasser del N i lokket.



Jx4
Nx2
Ox2

- 8** Søk assistanse og få noen til
å holde lokket på plass, mens
du monterer lokket med 4 stk
I-skruer og 4 stk K-muttere.



Ix4
Kx4

OBS! To personer bør utføre
dette steget. Hold lokket så ikke
produktet blir ødelagt.


MONTERING

- 9** Hold lokket på plass og monter 2 stk del F, fjær til lokk.
Stram tilslutt med en skiftenøkkel.




OBS! Klemfare!

OBS! To personer bør utføre dette steget. Hold lokket så ikke produktet blir ødelagt.




Fx2

Bildet til venstre viser hvordan mutteren skal festes.



ADVARSLER

- Påse at vann dreneres fra putekassen og at den ikke blir stående med vann i rammeverket. Dette kan skape frostspreng og dekkes ikke av reklamasjon.
 - Alle metaller kan ruste gitt de riktige forutsetningene. Aluminium har ekstremt høy motstandsdyktighet, men jevnlig renhold og vedlikehold vil øke levetiden.
 - Salter, saltvannsluft, fugleskitt, riper i lakket og annet kan over tid skade lakken. Sørg for jevnlig renhold for å unngå dette.
 - Obs! Skarpe kanter kan forekomme. Vi har gjort alt vi kan for å fjerne skarpe kanter under produksjonen, men vi anbefaler å utøve forsiktighet og bruke hansker ved håndtering.
 - **DETTE PRODUKTET ER BEREGNET FOR BRUK I PRIVATE HUSHOLDNINGER OG ER IKKE EGNET FOR PROFESJONELL BRUK.**
 - Lakkerte overflater kan påvirkes av sollys. Dette påvirker ikke putekassens funksjoner og er ingen reklamasjon.
 - Lakkerte overflater kan slites/ripes ved bruk, dette må utbedres for å unngå rustdannelse i overflatesår.
 - Putekassen må kun brukes til egnet formål, ikke overbelastes utover maks vekt eller utsettes for annen belastning/slitasje. Påse at store snømengder eller isdannelse fjernes med jevne mellomrom og ikke blir liggende over lang tid.
 - Dersom putekassen overbelastes kan skjøter og fester skades, noe som kan påvirke konstruksjon og styrke. Dette er ingen reklamasjon.
 - Sjekk for ev. skader på produktet før det monteres.
Ta kontakt med support@nordicseason.no ved spørsmål.
 - Overflaten på møbelet kan bli veldig varm i direkte sollys. Vær obs og unngå berøring ved høy temperatur da dette kan føre til personskader.
 - Putekassen er beregnet for utendørs bruk.
 - Elektroverktøy skal ikke anvendes ved montering. Verktøy med for stor kraft kan skade overflatebehandlingen på skruer, skade lakkerte deler, samt løsne forhåndsmonterte muttere.
 - Om man entrer skruene feil, drar til for hardt eller bruker elektroverktøy, vil gjengene skades. Aluminiumsrammene kan også bøyes dersom man skrur til for hardt. Dette dekkes ikke av garantien.
 - Hold barn og andre som trenger tilsyn på sikker avstand for å unngå at produktet brukes til klatring. Skader kan oppstå.
 - Vi anbefaler på det sterkeste å oppbevare puter og andre tekstiler innendørs om vinteren.
- IKKE BRUK PUTEKASSEN TIL LANGTIDSOPPBEVARING AV TEKSTILER/PUTER.**



Max vekt: 80 kg

VEDLIKEHOLD

- Aluminium krever mindre vedlikehold, men kan korrodere i fuktige og salte miljøer over tid.
- Påse regelmessig rengjøring av møbelet med mildt såpevann og myk børste eller svamp. Blir møbelet utsatt for mye sur nedbør, forurensning, fugleskitt og lignende kan det etse på overflatebehandlingen og skape stygge merker. Rengjør overflaten med rent vann til slutt for å fjerne såperester.
- Vær klar over at selv om aluminium tåler mye, så tåler det ikke alt. Aluminium tåler ikke å bli bøyd mange ganger, og i nærheten av salter, saltvann og metaller av andre legeringer kan det oppstå korrosjon. Aluminium er i utgangspunktet rustfritt, men dersom det står utsatt til kan det oppstå korrosjon.
- Dersom det kommer overflateskader på møbelet slik at lakken fjernes, anbefales det å reparere med lakkpenn eller tilsvarende for å unngå oksydering. Kontakt din nærmeste forhandler.
- Rengjør møblene med vann og mildt såpevaskemiddel. Skyll av ved å sprute med hageslange. Ikke bruk høytrykksspyler, da dette kan skade møblene og overflatebelegget.

OPPBEVARING & LAGRING

- Rengjør møblene før du pakker de bort og sørg for å gi de ekstra beskyttelse. Bruk egnede rengjøringsprodukter og tørk over til slutt med en fuktig klut.
 - Sørg for at møblene er tørre og ikke oppvarmet før de lagres under møbeltrekk. Gjøres ikke dette kan det skapes reaksjon med trekket, som resulterer i flekker og skjemmer utseendet på møblene. Er det fuktighet i møblene kan dette skape frostspreng i rammen eller skjøter. Dette kan utvide seg og skade strukturen hvis det dannes is. Sjekk at det ikke er vann i rammen før lagring, dette må ev. dreneres i dreneringshullene.
 - Vinterlagres møblene under et overtrekk må du sørge for god ventilasjon.
 - Møblene må lagres riktig vei opp slik at vann ikke kan trenge inn i rammeverket.
 - Vær oppmerksom på at skader som oppstår på grunn av feil lagring og/eller frostspreng ikke dekkes av reklamasjon.
 - Vi anbefaler på det sterkeste å oppbevare puter og andre tekstiler innendørs om vinteren.
- IKKE BRUK PUTEKASSEN TIL LANGTIDSOPPBEVARING AV TEKSTILER/PUTER.**



REKLAMASJONSRETT

Dette produktet er dekket med reklamasjonsrett i henhold til forbrukerlovgivningen. Produktet gjennomgår streng kvalitetskontroll og testing på fabrikk. Skulle det mot formodning mangle deler i pakken eller produktet være skadet, ta kontakt med forhandler eller nedenstående forbrukerkontakt for videre hjelp.

Ved skader på produktet ber vi om at bilder av skaden og produktets emballasje vedlegges reklamasjonen.

Defekter som skyldes feilbruk, manglende vedlikehold eller modifikasjon av produktet, medfører bortfall av reklamasjonsretten.

Ødelagte deler som ikke skyldes reklamasjon, faktureres etter gjeldene prisliste+frakt og ekspedisjonsgebyr.

Ved behov for deler eller ved reklamasjon, ta kontakt med forhandler eller forbrukerkontakt.

Forbrukerkontakt:

Nordic Season Products AS

Kjeller Vest 3

2007 Kjeller, Norge

E-post: support@nordicseason.no

Tlf: 0047 924 78 600 (10–14 man–fre)


www.nordicseason.no

Ved reklamasjon på produktet skal kjøpsbevis vedlegges
Produsert i Kina for Nordic Season Asia Co., Ltd.



CUSHION BOX

650L ALUMINUM












EN

Assembly instructions

PARTS LIST

Make sure all parts and screws are included and that they are undamaged before assembling the product. If the unit is damaged in transport, the unit must not be assembled before contacting the dealer.

Damaged parts or damage on the paint caused by transport, must be reported to the dealer before the unit is assembled and put into use. Please note that some parts may be hidden in the styrofoam to protect the part in transport. If parts are missing, check the packaging carefully.

Ax1		Bx1		Cx2	
Dx1		Ex1		Fx2	
Gx1		Hx1		Ix20	 M4*8
Jx4	 M4*12	Kx26	 M4	Lx6	
Mx2		Nx2		Ox2	
Px2		Qx1	 7mm	Rx1	 12#
Sx1	 5*50	Tx6	 M4	Ux22	 M4

PARTS

No.	Description	Qty
A	Lid	1
B	Bottom panel	1
C	Left and right side walls	2
D	Rear wall	1
E	Front wall	1
F	Lid damper	2
G	Lock	1
H	Lock part	1
I	M4x8 screw	20
J	M4x12 screw	4
K	M4 nut	26
L	Feet	6
M	Sleeve	2
N	Spacer, bumper, gasket	2
O	Lid hinge	2
P	Key	2
Q	Hex key/socket spanner	1
R	Spanner	1
S	Philips screwdriver	1
T	M4 nut	6
U	M4 Washer	22

Insert all screws first, do not tighten. Tighten all screws when module is fully assembled.

WARNING!

DO NOT USE ELECTRICAL TOOLS TO ASSEMBLE THE FURNITURE.

TOOLS WITH EXCESSIVE FORCE MAY DAMAGE THE SURFACE COATING OF SCREWS, DAMAGE ENAMEL/PAINTED PARTS OF THE MODULES, AND LOOSEN PRE-FITTED NUTS.

TIP!


If the furniture appears crooked or bowed after fully assembled, loosen all the screws. Straighten each part and tighten screws again. Assemble the box on a flat surface for the best possible result.

ASSEMBLY

PLACE A PIECE OF CARDBOARD ON THE FLOOR (E.G THE OUTER CARTON) TO PREVENT SCRATCHING THE UNIT AND PARTS DURING ASSEMBLY.

1


Mount all screws and nuts. Do not tighten until step 4. Assemble part C1, C2 and D together with 8 pcs I screws, 8 pcs U washers and 8 pcs K nuts.



Ix8
Kx8
Ux8

2

Mount part B with 3 pcs L feet, 3 pcs U washer, 3 pcs T nut and 3 pcs K nut.




Kx3
Lx3
Tx3
Ux3

ASSEMBLY

3


Mount part E with 2 pcs I screw,
2 pcs U nut and 2 pcs K nut.



Ix2
Kx2
Ux2

4

Mount part B with 3 pcs L feet,
3 pcs U washer, 3 pcs T nut and
3 pcs K nut. Secure part E with
6 pcs I screw, 6 pcs U nut and
6 pcs K nut.




Ix6
Kx9
Lx3
Tx3
Ux9

Tighten all screws after step 4.

ASSEMBLY


- 5** Mount lock part G and sleeve part M.



Place the
installation
horizontally

Gx1
Mx2

- 6** Place lock part H and secure with 1 screw.




Place the
installation
horizontally

Hx1

ASSEMBLY

- 7** Mount 2 pcs O hinge with 4 pcs J screw.
Place part N in the lid.


Jx4
Nx2
Ox2



- 8** Get assistance from another person, to hold the lid in place while mounting the lid with 4 pcs I screw and 4 pcs K nuts.

Ix4
Kx4

NOTE: Two people should perform this step. Hold the lid to avoid damaging the product.




ASSEMBLY

9 Hold lid and mount 2 pcs F lid damper. Tighten with a spanner.




NOTE! Mind your hands

NOTE! Two persons should perform this step. Hold the lid while fastening, to avoid damaging the product.




Fx2

Left image shows the correct placing of nut.



WARNING!

- Make sure that water is drained from the cushion box and not left with water in the framework. This can create frostbite and is not covered by complaints.
- All metals can rust under the right conditions. Aluminum has an extremely high resistance, but regular cleaning and maintenance will increase its lifespan.
- Salts, sea air, bird droppings, paint scratches, and other strain may harm the finish over time. Clean regularly to prevent this from occurring.
- Note! The furniture may have sharp edges. We have done our best to remove sharp edges during production, but we recommend to exercise caution when handling the product.
- **THIS PRODUCT IS DESIGNED FOR USE IN DOMESTIC HOUSEHOLDS AND IS NOT INTENDED FOR COMMERCIAL USE IN RESTAURANTS OR SIMILAR VENUES.**
- The lacquered surface of the cushion box may be affected by sunlight. This does not affect the functionality and is not covered by warranty.
- The lacquered surface of the cushion box can be worn/scratched during use. This must be fixed to prevent rust from forming in damaged surface areas.
- The furniture must only be used for its intended purpose and must not be exposed to weight exceeding its maximum specification nor exposed to other loads/strain. Make sure that large amounts of snow or ice formation are removed at regular intervals and do not remain for long periods of time.
- If the furniture is overloaded, the joints and fittings may be damaged, affecting the furnitures strength and structure. This is not covered by warranty.
- Check for the presence of any damage before assembly. Contact support@nordicseason.no for any inquiries.
- The surface of the furniture may become very hot in direct sunlight. Please be aware of this and avoid use in high temperatures, as this may cause injury.
- The furniture is intended for outdoor use.
- Do not use electrical tools to assemble the furniture. Tools with excessive force may damage the surface coating of screws, damage enamel/painted parts, and loosen pre-fitted nuts.
- Inserting screws wrongly, torquing with excessive force, or using electrical tools may damage the threading. The aluminum frames can bend if you tighten the screws too hard. Damage as such will not be covered by the warranty.
- Keep children and others who require supervision at a safe distance away to prevent them from climbing on the furniture. This may entail a risk of injury.
- We strongly recommend storing cushions and other textiles indoors during winter.
DO NOT USE THE BOX FOR LONG-TERM STORING OF TEXTILES/CUSHIONS.



Max load: 80 kg

MAINTENANCE

- Aluminum requires less maintenance, but it may corrode over time in damp and salty environments.
- Ensure regular cleaning with gentle soapy water and a soft brush or sponge. If the furniture is exposed to a lot of acid rain, pollution, bird droppings, and similar waste that can corrode the surface treatment and leave ugly stains. Clean the surface with clean water at the end to remove remaining soap.
- Please note that while aluminum can handle a lot, it can't take everything. It won't withstand being bent repeatedly, and corrosion may occur in the presence of salts, salt water, and other metal alloys. Aluminum is generally considered rust-free, but corrosion may occur if it is left exposed.
- If the furniture takes surface damage that removes the paint, we recommend using a paint repair pen or similar tool to prevent oxidization. Contact your nearest retailer.
- Use a garden hose for cleaning.
- Do not use a pressure washer as this may harm the furniture and its surface coating.

SHORT AND LONG-TERM STORAGE

- Clean the module before storing and make sure to provide it with extra protection. Use suitable cleaning products and wipe it down with a damp cloth.
- Make sure that the module is dry and not heated before storing under a module cover. Moisture under the cover may create a reaction with the cover, or leave stains or undesirable marks on the module. Moisture on the module, also may cause frost damage to the frame or joints. Water turned to ice will expand and damage the structure if ice forms. Ensure that there is no water in the frame before storage. If present, any water must be drained using the drainage holes.
- If you are storing the module in a cover during the winter, ensure proper ventilation.
- The module must be stored right side up to prevent water from entering the frame.
- Please note that damage caused by improper storage and/or frost damage will not be covered by warranty.
- If the module is stored outdoors all year, make sure that water is drained from the module and not left standing with water in the frame. This can cause frost damage and will not be covered by warranty.
- We strongly recommend storing cushions and other textiles indoors during winter.

DO NOT USE THE BOX FOR LONG-TERM STORING OF TEXTILES/CUSHIONS.



WARRANTY CLAIM

This product is covered by a warranty in accordance with consumer legislation. It has undergone strict quality controls and testing at the factory. If there are any parts missing or the product has been damaged, please contact your dealer or the consumer contact below for help.

In the event of damage to the product, we ask for pictures of the damage and damage to the product's packaging is attached to the complaint.

Faults due to misuse, lack of maintenance or modification of the product will invalidate the warranty.

Damaged parts not due to a fault with the product will be invoiced according to our price list + carriage and administration fee.

If new parts are needed or in the event of a warranty claim, please contact your dealer or consumer contact.

Consumer contact:

Nordic Season Products AS

Kjeller Vest 3

2007 Kjeller, Norge

e-mail: support@nordicseason.no

tlf: 0047 924 78 600 (10–14 mon–fri)

www.nordicseason.no

Always attach your receipt when making a warranty claim.

Produced in China for Nordic Season Asia Co., Ltd.