





Mill Gentle Air WiFi oil filled radiator Illustrations mill[®]


1. DESCRIPTION OF THE HEATER



2. PARTS



3. ASSEMBLY




4. TEMPERATURE CALIBRATION




5. POWER INDICATOR



6. RESETTING THE HEATER




7. INSTRUCTIONS






8. USAGE WITHOUT WIFI CONNECTION



9. TIMER FUNCTION WITHOUT WIFI CONNECTION




10. ACTIVATING WIFI



11. DEACTIVATING WIFI



12. RECONNECTING WIFI



13. DELETE WIFI SETTINGS

